

# QLogic 4Gb Fibre Channel Expansion Card (CIOv) for BladeCenter

## Product Guide (withdrawn product)

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) for BladeCenter enables you to quickly and simply connect the BladeCenter servers with CIOv expansion slots to a Fibre Channel SAN. Simply pick any Fibre Channel storage solution and begin accessing data over a high-speed interconnect.

This card is installed into the PCI Express CIOv slot of a supported blade server. It provides connections to Fibre Channel-compatible modules located in bays 3 and 4 of supported BladeCenter chassis. A maximum of one QLogic 4Gb Fibre Channel Expansion Card (CIOv) is supported per single-wide (30 mm) blade server.

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) is shown in Figure 1.



Figure 1. QLogic 4Gb Fibre Channel Expansion Card (CIOv)

### Did you know?

The adapter connects to the midplane directly, without having to use cables or SFP modules. By eliminating these components for up to 14 servers, the resulting savings alone cover the BladeCenter chassis investment.

The adapter is based on the PCI Express bus, which can be thought of as a high-speed serial replacement of the older technology. Its use offers many benefits, including higher speeds and the ability to send and receive data at the same time.

When using the CIOv adapter, you can simultaneously use a CFFh adapter to enable more types of I/O to supported blade servers such as the HS22 when installed in the BladeCenter H chassis. The innovative design of the CIOv adapter works with the CFFh adapter to support this combination.

## Part number information

The part number to order this card is shown in Table 1.

Table 1. Ordering part number and feature code

Description	Part number	Feature code
QLogic 4Gb Fibre Channel Expansion Card (CIOv) for BladeCenter	46M6065*	3594 / 8241**

\* Withdrawn from marketing

\*\* The first feature code is for use with the System x sales channel. The second feature code is for use with the Power Systems sales channel

The part number includes the following items:

- One QLogic 4Gb Fibre Channel Expansion Card (CIOv) for BladeCenter
- Documentation package

## Features

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) has the following features:

- CIOv form factor
- PCI Express 2.0 host interface
- Support for two full-duplex Fibre Channel ports at 4 Gbps maximum per channel
- Support for Fibre Channel Protocol SCSI (FCP-SCSI) and Fibre Channel Internet Protocol (FC-IP)
- Support for Fibre Channel service (class 3)
- Support for switched fabric, point-to-point, and Fibre Channel Arbitrated Loop (FC-AL) connections
- Configuration and boot support in BIOS and UEFI

## Operating environment

The expansion card is supported in this environment:

- Temperature:
  - 10 to 35°C (50 to 95°F) at 0 to 914 m (0 to 3,000 ft)
  - 10 to 32°C (50 to 90°F) at 914 to 2,133 m (3,000 to 7,000 ft)
- Relative humidity: 8% to 80%
- Maximum altitude: 2,133 m (7,000 ft)

## Supported servers and I/O modules

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) is supported in the BladeCenter servers listed in Table 2.

Table 2. Supported servers

		HS12	HS21	HS21 XM	HS22	HS22V	HX5	LS21	LS22	LS41	LS42	JS12	JS21	JS22	JS23/JS43	PS700/1/2
QLogic 4Gb Fibre Channel Expansion Card (CIOv)	46M6065	N	N	N	Y	Y	Y	N	N	N	N	N	N	N	Y	Y

See IBM ServerProven for the latest information on the expansion cards supported by each blade server type: <http://ibm.com/servers/eserver/serverproven/compat/us/>.

CIOv expansion cards are installed in the CIOv slot in supported servers such as the HS22 as highlighted in red in Figure 2.




Figure 2. Location of the CIOv slot in the BladeCenter HS22

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) supports the I/O modules listed in Table 3. The table also lists the BladeCenter chassis that support each I/O module.

The card requires that a supported I/O module is installed in bay 3 or bay 4 of the chassis, however for redundancy and performance purposes, we recommend that you install two I/O modules in the chassis, one in bay 3 and one in bay 4 of the chassis.

Table 3. I/O module and chassis combinations supported with the QLogic 4Gb Fibre Channel Expansion Card (CIOv)

		BladeCenter S	BladeCenter E	BladeCenter H	BladeCenter T	BladeCenter HT
Brocade 4 Gb 20-port SAN Switch Module	32R1812	N	Y	Y	Y	Y
Brocade 4 Gb 10-port SAN Switch Module	32R1813	Y	Y	Y	Y	Y
Brocade Enterprise 20-port 8Gb SAN Switch Module	42C1828	N	Y	Y	N	Y
Brocade 20-port 8Gb SAN Switch Module	44X1920	N	Y	Y	N	Y
Brocade 10-port 8Gb SAN Switch Module	44X1921	N	Y	Y	N	Y
Cisco 4 Gb 20-port Fibre Channel Switch Module	39Y9280	N	Y	Y	Y	Y
Cisco 4 Gb 10-port Fibre Channel Switch Module	39Y9284	Y	Y	Y	Y	Y
McDATA 4 Gb 20-port Fibre Channel Switch Module	32R1833	N	Y	Y	Y	Y
McDATA 4 Gb 10-port Fibre Channel Switch Module	32R1905	N	Y	Y	Y	Y
QLogic 4 Gb 20-port Fibre Channel Switch Module	26R0881	N	Y	Y	Y	Y
QLogic 4 Gb 10-port Fibre Channel Switch Module	32R1904	N	Y	Y	Y	Y
QLogic 20-port 4 Gb SAN Switch Module	43W6725	N	Y	Y	Y	Y
QLogic 10-port 4 Gb SAN Switch Module	43W6724	Y	Y	Y	Y	Y
QLogic 20-Port 8 Gb SAN Switch Module	44X1905	Y	Y	Y	Y	Y
QLogic 8 Gb Intelligent Pass-thru Module	44X1907	Y	Y	Y	Y	Y
QLogic 4 Gb Intelligent Pass-thru Module	43W6723	Y	Y	Y	Y	Y

Important considerations:

- The BladeCenter Optical Pass-thru Module, 39Y9316, is not supported.
- The BladeCenter S does not support all I/O modules, as shown in Table 3.
- Many of the I/O modules listed in the table also support the Multi-Switch Interconnect Module (MSIM) and MSIM-HT. However, we do not list that support here since CIOv expansion cards do not support the use of the MSIM or MSIM-HT.

## Popular configurations

This section illustrates how the QLogic 4Gb Fibre Channel Expansion Card (CIOv) can be used in configurations. Figure 3 shows the CIOv card installed in a supported blade server, which is in turn installed in a BladeCenter chassis. The chassis is connected to the IBM System Storage DS3400. The RAID functionality is provided by the external storage system.




Figure 3. BladeCenter connected to an external IBM System Storage DS3400 storage solution

The parts used in this configuration are listed in Table 4.

Table 4. Components used when connecting the QLogic 4Gb Fibre Channel Expansion Card (CIOv) to external disk storage (as shown in Figure 3)

Diagram reference	Part number / Machine type	Description	Quantity
1	Varies	BladeCenter HS22 or other supported server	1 to 14
2	46M6065	QLogic 4Gb Fibre Channel Expansion Card (CIOv)	1 per server
3	8677 or 8852*	BladeCenter E, BladeCenter H, or BladeCenter S*	1
4	Varies	Any Brocade, QLogic or Cisco Fibre Channel Switch module	1 or 2
5	1726-41X or 1726-42X	IBM System Storage DS3400 (Single or Dual Controller)	1
6	1727	Optional IBM System Storage EXP3000 (Single or Dual ESM)	1 to 3
7	39R6536	DS3000 Partition Expansion License	1

\*Note: The expansion card can be installed in servers in the BladeCenter S (8886). However, by doing so you will lose the ability to connect to the BladeCenter S Disk Storage Modules (DSMs). The Fibre Channel expansion card will go in the place of the SAS expansion card needed to connected to the DSMs.

This configuration will also require cabling between the chassis and the storage server and between the storage server and expansion units. (The cable part numbers are not listed in Table 3.)

## Supported operating systems

The QLogic 4Gb Fibre Channel Expansion Card (CIOv) supports the following operating systems:

- IBM AIX 5L for POWER Version 5.3
- IBM AIX Version 6.1

- IBM Virtual I/O Server
- IBM i operating system 6.1
- Microsoft Windows Essential Business Server 2008 Premium Edition
- Microsoft Windows Essential Business Server 2008 Standard Edition
- Microsoft Windows Server 2003 R2 Datacenter Edition Unlimited Virtualization
- Microsoft Windows Server 2003, Web Edition
- Microsoft Windows Server 2003/2003 R2, Enterprise Edition
- Microsoft Windows Server 2003/2003 R2, Enterprise x64 Edition
- Microsoft Windows Server 2003/2003 R2, Standard Edition
- Microsoft Windows Server 2003/2003 R2, Standard x64 Edition
- Microsoft Windows Server 2008 R2
- Microsoft Windows Server 2008, Datacenter x64 Edition
- Microsoft Windows Server 2008, Datacenter x86 Edition
- Microsoft Windows Server 2008, Enterprise x64 Edition
- Microsoft Windows Server 2008, Enterprise x86 Edition
- Microsoft Windows Server 2008, Standard x64 Edition
- Microsoft Windows Server 2008, Standard x86 Edition
- Microsoft Windows Server 2008, Web x64 Edition
- Microsoft Windows Server 2008, Web x86 Edition
- Microsoft Windows Small Business Server 2003/2003 R2 Premium Edition
- Microsoft Windows Small Business Server 2003/2003 R2 Standard Edition
- Microsoft Windows Small Business Server 2008 Premium Edition
- Microsoft Windows Small Business Server 2008 Standard Edition
- Red Hat Enterprise Linux 4 AS for x86
- Red Hat Enterprise Linux 4 ES for x86
- Red Hat Enterprise Linux 4 WS/HPC for x86
- Red Hat Enterprise Linux 4 for IBM POWER
- Red Hat Enterprise Linux 5 Server Edition
- Red Hat Enterprise Linux 5 Server Edition with Xen
- Red Hat Enterprise Linux 5 Server with Xen x64 Edition
- Red Hat Enterprise Linux 5 Server x64 Edition
- Red Hat Enterprise Linux 5 for IBM POWER
- SUSE LINUX Enterprise Server 10 for AMD64/EM64T
- SUSE LINUX Enterprise Server 10 for IBM POWER
- SUSE LINUX Enterprise Server 10 for x86
- SUSE LINUX Enterprise Server 10 with Xen for AMD64/EM64T
- SUSE LINUX Enterprise Server 10 with Xen for x86
- SUSE LINUX Enterprise Server 11 for AMD64/EM64T
- SUSE LINUX Enterprise Server 11 for IBM POWER
- SUSE LINUX Enterprise Server 11 with Xen for AMD64/EM64T
- VMware ESX 3.5
- VMware ESX 4.0
- VMware ESXi 3.5

- VMware ESXi 4.0

See IBM ServerProven for the latest information on the specific versions and service packs supported: <http://ibm.com/servers/eserver/serverproven/compat/us/>. Select the blade server and then select the expansion card to see the supported operating systems.

## Related publications

For more information refer to these documents:

- *QLogic 4Gb Fibre Channel Expansion Card (CIOv) Installation and User Guide* :  
<http://ibm.com/support/entry/portal/docdisplay?Indocid=MIGR-5079686>
- US Announcement Letter  
<http://ibm.com/common/ssi/cgi-bin/ssialias?infotype=dd&subtype=ca&&htmlfid=897/ENUS109-101>
- BladeCenter Interoperability Guide  
<http://lenovopress.com/bcig>

## Related product families

Product families related to this document are the following:

- [Blade Storage Adapters](#)

## Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area. Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service. Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

Lenovo (United States), Inc.  
8001 Development Drive  
Morrisville, NC 27560  
U.S.A.  
Attention: Lenovo Director of Licensing

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary. Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk. Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

© Copyright Lenovo 2024. All rights reserved.

This document, TIPS0695, was created or updated on June 19, 2013.

Send us your comments in one of the following ways:

- Use the online Contact us review form found at:  
<https://lenovopress.lenovo.com/TIPS0695>
- Send your comments in an e-mail to:  
[comments@lenovopress.com](mailto:comments@lenovopress.com)

This document is available online at <https://lenovopress.lenovo.com/TIPS0695>.



## Trademarks

Lenovo and the Lenovo logo are trademarks or registered trademarks of Lenovo in the United States, other countries, or both. A current list of Lenovo trademarks is available on the Web at <https://www.lenovo.com/us/en/legal/copytrade/>.

The following terms are trademarks of Lenovo in the United States, other countries, or both:

Lenovo®

BladeCenter Interoperability Guide

BladeCenter®

ServerProven®

System x®

The following terms are trademarks of other companies:

Linux® is the trademark of Linus Torvalds in the U.S. and other countries.

Microsoft®, Windows Server®, and Windows® are trademarks of Microsoft Corporation in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.